



NOTES:

1. SEE CURLEX® NETFREE™ SLOPE APPLICATION DETAIL SHEET FOR PROPER SLOPE INSTALLATION.
2. STAPLE PATTERNS ARE DEPENDENT ON SITE CONDITIONS. SEE CURLEX® NETFREE™ STAPLE PATTERN GUIDE FOR DETAILS.
3. E-STAPLE® MAY BE USED IN PLACE OF WIRE STAPLES.



CHANNEL INSTALLATION METHOD "A"
NO SCALE

14




CHANNEL INSTALLATION METHOD "B"
NO SCALE

14


CHANNEL DETAIL
NO SCALE

14




CHANNEL TERMINATION PLAN
NO SCALE

14




CHANNEL TERMINATION
NO SCALE

14



SIDE SEAM OVERLAP STAPLE DETAIL
NO SCALE

14




CHANNEL BLANKET END OF ROLL OVERLAP
NO SCALE


14

CHANNEL TRENCHING METHOD "A"
NO SCALE


14




STEP 1



STEP 2



STEP 1



STEP 2

CHANNEL TRENCHING METHOD "B"
NO SCALE

14

NO.	REV.	DATE	REVISIONS	PROJECT	APPROVED BY:	DATE	SCALE	DRAWN BY:	SHEET NO.
				AMERICAN EXCELSIOR COMPANY	CURLEX® NETFREE™ CHANNEL APPLICATION DETAIL	2/6/04	NONE		14
				ARLINGTON, TEXAS					
				AMERICAN EXCELSIOR COMPANY					
				Earth Science Division					